

# Your Cargo Unloads Itself.

Drop the gate. Pull the strap. Gravity does the rest.

## FOUR STEPS. FIVE MINUTES. ZERO TOOLS.


**1**  
**STACK & ORIENT**  
Lay all Power Panels on your tailgate. Make sure every **Snap-Lock tab** faces the same direction — down and to the right.

**2**  
**BUILD ROWS**  
Work left to right. Slide one panel's Snap-Lock tab into the next panel's groove. Listen for the click.

**3**  
**ADD EDGE STRIPES**  
Snap Edge Stripes onto the **left & right long edges** only — they widen the system to clear your wheel wells.

**4**  
**DROP & PULL**  
Connect rows back-to-front. Lift assembly into bed. Gravity Hinge anchors at tailgate. Drop the gate, pull the strap.


## ASSEMBLY DIAGRAM



### WHAT'S IN YOUR BOX

- Power Panels — black, large
- Edge Stripes — orange in diagram (black in box)
- Cargo Walls — 4 snap-in dividers
- Tall Caps — 2 vertical holders
- Gravity Hinge + Strap

## HOW SNAP-LOCK™ WORKS



**INSERT REAL PRODUCT PHOTO HERE**

Close-up of two panels mid-snap, showing the male tab sliding into the female groove. Macro shot ~3" wide.

✓ RIGHT VS X WRONG ORIENTATION

✓ ALL TABS FACE SAME WAY



All male tabs pointing RIGHT


X MIXED DIRECTION = WON'T LOCK



Tab #2 backwards — will not connect

3 RULES — READ BEFORE YOU SNAP

- **Direction matters.** All Snap-Lock tabs must face the same way (down + right). Re-orienting mid-build means full disassembly.
- **Edge Stripes only attach to LEFT & RIGHT sides.** Never top or bottom. The system widens — it does not lengthen — with strips.
- **Gravity Hinge goes at the TAILGATE END.** That last 6-7" of bed is the **Gravity Hinge Zone** — where the hinge mechanism deploys and where your cargo lands when you pull the strap. It is engineered space, not empty space.



SCAN FOR YOUR TRUCK'S EXACT LAYOUT

Watch the video. See your bed's specific diagram. Get coverage % for your model. Order replacement parts.

[buycargobutler.com/fit](https://buycargobutler.com/fit)

## Troubleshooting & Care.

Stuff happens. Here's how to fix it in 30 seconds.

### COMMON ISSUES

#### PANELS WON'T SNAP TOGETHER

Check Snap-Lock orientation — all male tabs must face the same direction (down + right). Re-orient any backwards panel before continuing.

#### EDGE STRIPES ARE LOOSE

Press firmly until you hear a click. Stripes only attach to the LEFT and RIGHT long edges — never top or bottom.

#### ASSEMBLY IS TOO WIDE FOR MY BED

Remove the outermost column of Edge Stripes. The Max-Width add-on (4 strips per side) is optional for narrow beds.

#### THERE'S A GAP AT THE TAILGATE

That's by design. The Gravity Hinge mechanism deploys into that zone — it's where your cargo slides when you pull the strap.

#### CARGO WALLS WON'T STAY VERTICAL

Align peg with grid hole. Press down with even pressure. They can be repositioned anywhere on the grid.

#### HOW DO I REMOVE IT?

Pull the carry strap straight up. The whole assembly lifts out in one piece — 22 lb total. No tools, no marks left behind.

### ⚠ READ BEFORE USE

- Cargo Butler™ is designed for enclosed and covered truck beds, SUV cargo areas, and minivans. Always secure loose items before driving — gravity hinge does NOT replace tie-downs for hazardous, fragile, or wind-exposed cargo.
- Maximum load: **500 lb evenly distributed**. Do not stack heavy point loads (e.g., engines, anvils) directly on a single panel.
- Do not use with the tailgate down while driving. The Gravity Hinge is only active when the tailgate is DOWN AND THE VEHICLE IS PARKED.
- Do not stand or jump on the panels. They support cargo, not human body weight.

### CARE & CLEANING



#### RINSE WITH WATER

Hose off after muddy loads. Drain holes built in.



#### MILD SOAP OK

Dish soap + soft brush for stubborn dirt.




#### NO SOLVENTS

Avoid bleach, gasoline, or acetone — damages the polymer.

### WARRANTY & RETURNS

#### 90-DAY BED TEST

- **Don't love it?** Send it back within 90 days. We cover return shipping if unopened. Used and unhappy? We'll still take it back.
- **Lifetime Warranty (add-on, \$39):** Free replacement of any cracked or warped Power Panel or Edge Stripe — for life.
- Returns: [buycargobutler.com/returns](https://buycargobutler.com/returns) · Email: [hello@buycargobutler.com](mailto:hello@buycargobutler.com) · Call: 1-800-XXX-XXXX





## FIND YOUR TRUCK'S EXACT DIAGRAM

Coverage %, parts list, installation video tailored to your truck model + bed size.

[buycargobutler.com/fit](https://buycargobutler.com/fit)